


## Automatic Controller Operation Guide – West Field


Zone	Location	Program 1	Program 2	Program 3	Program 4	Program 5	Program 6
		Start of Day	HT/FT				
1	Scoreboard	2 mins	45 secs				
2	Dugout	3 mins	60 secs				
3	SE Carpark	2 mins	45 secs				
4	SW Carpark	2 mins	45 secs				
5	Western middle	3 mins	60 secs				
6	NW Highway	2 mins	45 secs				
Program Run Time		<b>14 Mins</b>	<b>4m 30 secs</b>				

### To activate a automatic program


1. Turn dial to required program as per table above




2. Select the Zone number corresponding to first Zone to run (refer to table above)



3. Select "Manual On/Off"



4. Return dial to "Auto"



5. Hooter will sound, cannons will cycle through program and end automatically

### Terminating a Watering Cycle

Turn dial to program in operation and press Manual On/Off key. Return dial to Auto position.