



URGQ Club House Compressor Procedure

1. Check compressor oil
2. Turn key switch to ON, wall fan will start, followed by the compressor (15 seconds delay)
3. Press START button
4. Flush lines of dirty air
5. Record tank owner and Test Date (must be current)
6. Attach empty tanks to filling hoses
7. Only fill tanks with paid tags
8. Compressor will shut off at 240 bar
9. After tanks have been changed, compressor will start automatically
10. While filling, observe CO reading and record in log (should CO reading go higher than 5ppm, an audible alarm will sound – switch off the compressor immediately)
11. When filling is complete, switch off key switch and drain air from system – slowly!!!
12. Log run hours
13. Filter drains are automatic
14. P41 Securus filter is monitored and will indicate when replacement is required (spare in stock)

URGQ Date Revised – June 2023

Compressor operation by authorised operators only (see website for nominated compressor operators)

By Order – President